

# FlashPARCS

## How to use BLE for Monthly Access


FlashPARCS supports a Bluetooth Low Energy (BLE) feature that allows frictionless access for registered monthly parkers.

### How Does It Work?

Each entry and exit kiosk is outfitted with a BLE device. Using the FlashParking app, monthly parkers can select an option from the app to open the gate to the facility once within Bluetooth range of the kiosk.

1. Ensure the monthly parking account in the Admin Portal has the parker's **mobile number stored**
2. Download the **FlashParking app** from the App Store.
3. Follow the prompts in the app to **verify your mobile number**.
4. From the Home tab, select **Enter Garage > Open Gate**

From the menu icon in the top left of the screen, the monthly parker can **update their account profile, vehicles, and stored credit cards**.



#### Please note:

All monthly parkers should have a **prox card stored to their account** in the Admin Portal.

If the **loop is not armed** when you press **Open Gate**, the app will continue to try to execute the command until the loop is armed. If you press the Open Gate button a second time, you will be presented with an option to STOP the scan with YES/NO dialogue box.

If the **loop is not armed** when you **scan the barcode** from the app, you will receive an Invalid Item error on the kiosk.

If the app is within correct proximity to the kiosk, the Open Gate button will be **grayed out** when it is about to execute the open gate command.

